

「レフレックス+再生」式単球ラジオ基板対応表

感度は球の元気具合にも依存する。

青文字は予定中

BASE	9AE	9AT	9DA	9DC	9DX	9DW	9ED	9EG	9EX	9FA	9FT	9FZ	9GF	9GM	9JF	9JG	9KN	9LZ	9LY	9MP	9PA	9PV	9QA	9QP	9QT	9QY	9AE
適合TUBE	6GH8	6AB8	6AN8	6KE8	6AW8	6AT8	6AZ8	6BE8	6HC8	6BR8	6CH8	6KZ8	6GS7	6CU8	6EU8	6EH8	6GV7	6GW8	6GV8	6HG8	6JC8	6KA8	6GX7	6KT8	6KY8	6LC8	6U8
				6BL8	6AU8					6JN8			6FG7										6GJ7		6LR8		6AX8
				6JW8	6BA8								6CG8										6HB7				6EA8
				6EB8																							6LM8
				6HF8																							6MQ8
	7500uモ	3400uモ	7800uモ	6GN8	4600uモ	6000uモ	4500uモ	5800uモ	5200uモ	6200uモ			7800uモ	6400uモ	7500uモ	11000uモ		7500uモ	12000uモ		4400uモ				8400uモ	4400uモ	6MU8
				6KR8																							
				6KV8																							
				6JV8																							
				6MV8																							
基板番号	RK-176			RK-194	RK-183					RK-330	RK-204	RK-203			RK-193					RK-202			RK-192	RK-201			RK-189
感度	良好			超良好	超良好					劣る	良好				劣る							劣る	良好				良好
			try	初心者向け										try													RK-176 の改良版