

大まかな部品表	rk207	RADIO KITS IN JA	
名称	型式	員数	
socket	B9A	2	
tube	12AU7	2	
OP AMP	2ch 8DIP	1	
IC SOCKET	8 DIP	1	
D1,D2,D3,D4	IN4148等	4	
LED	blue	1	
VR :	100k A :RK97	1	2回路用
VR :	100k B :RK97	2	2回路用
JACK	PJ-320	2	
SW	SS12d00G5	1	
TR	2SC2120	2	
TR	2SA950	2	
R1,R15,R31,R45	10K	4	1/6W
R2,R32	47K	2	↓
R3,R33	120	2	
R4,R6,R34,R36	22K	4	
R5,R10,R35,R40	470K	4	
R7,R37	300K	2	
R8,R38	150K	2	
R9,R39	2.7M	2	
R11,R41	15K	2	
R12,R42	180	2	
R13,R43	330	2	
R14,R44	51K	2	
R16,R17,R46,R47	2.2K	4	
R18,R19,R48,R49	1	4	
R51,R52	1K	2	
C1,C3,C31,C33	100uF	4	
C2,C6,C8,C32,C36,C38	473	4	
C4,C7,C34,C37	152	4	
C5,C35	103 或いは153		
C12,C42	基本不要(ic特性に依存)		
C13,C43	470uF	2	25V
C51	1000uF 或いは 470uF	1	25V
C52,C54	104	2	
C53	470uF	1	25V
<b>ケミコンの低ESR品はNG ( op ampが発振しやすい挙動になる)</b>			
PINHEAD		1	
ツマミ		3	
樹脂スタット		4	
M3ネジ		4	
基板		1	
電源	12.6V 0.8A	1	
	電源トランスタイプ		